

Copyright Registration Information	Cisco	Arista															
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<table><tr><th>Related Commands</th><th>Command</th><th>Description</th></tr><tr><td></td><td>feature ptp</td><td>Enables or disables PTP on the device.</td></tr><tr><td></td><td>ptp source</td><td>Configures the source IP address for all PTP packets.</td></tr><tr><td></td><td>ptp domain</td><td>Configures the domain number to use for this clock.</td></tr><tr><td></td><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr></table> Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 337.	Related Commands	Command	Description		feature ptp	Enables or disables PTP on the device.		ptp source	Configures the source IP address for all PTP packets.		ptp domain	Configures the domain number to use for this clock.		ptp priority1	Configures the priority1 value to use when advertising this clock.	<p>ptp source ip</p> <p>The ptp source ip command configures the source IP address for all PTP packets. The IP address can be in IPv4 format. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 328.</p>
Related Commands	Command	Description															
	feature ptp	Enables or disables PTP on the device.															
	ptp source	Configures the source IP address for all PTP packets.															
	ptp domain	Configures the domain number to use for this clock.															
	ptp priority1	Configures the priority1 value to use when advertising this clock.															
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<table><tr><th>Related Commands</th><th>Command</th><th>Description</th></tr><tr><td></td><td>feature ptp</td><td>Enables or disables PTP on the device.</td></tr><tr><td></td><td>ptp source</td><td>Configures the source IP address for all PTP packets.</td></tr><tr><td></td><td>ptp domain</td><td>Configures the domain number to use for this clock.</td></tr><tr><td></td><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr></table> Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 337.	Related Commands	Command	Description		feature ptp	Enables or disables PTP on the device.		ptp source	Configures the source IP address for all PTP packets.		ptp domain	Configures the domain number to use for this clock.		ptp priority1	Configures the priority1 value to use when advertising this clock.	<p>ptp domain</p> <p>The ptp domain command configures the domain number to use for the clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 319.</p>
Related Commands	Command	Description															
	feature ptp	Enables or disables PTP on the device.															
	ptp source	Configures the source IP address for all PTP packets.															
	ptp domain	Configures the domain number to use for this clock.															
	ptp priority1	Configures the priority1 value to use when advertising this clock.															
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<table><tr><th>Command</th><th>Description</th></tr><tr><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr><tr><td>ptp priority2</td><td>Configures the priority2 value to use when advertising this clock.</td></tr><tr><td>show ptp brief</td><td>Displays the PTP status.</td></tr><tr><td>show ptp clock</td><td>Displays the properties of the local clock.</td></tr></table> Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.	Command	Description	ptp priority1	Configures the priority1 value to use when advertising this clock.	ptp priority2	Configures the priority2 value to use when advertising this clock.	show ptp brief	Displays the PTP status.	show ptp clock	Displays the properties of the local clock.	<p>Set the PTP Priority1</p> <p>To configure the priority1 value when advertising the clock, use the ptp priority1 command. This value overrides the default criteria for best master clock selection. Lower values take precedence.</p> <ul style="list-style-type: none">The ptp priority1 command configures the priority1 value of 120 to use when advertising the clock. <pre>switch(config)# ptp priority1 120 switch(config)#</pre> <p>Set the PTP Priority2</p> <p>To configure the priority2 value when advertising this clock, use the ptp priority2 command. This value is used to decide between two devices that are otherwise equally matched in the default criteria.</p> <ul style="list-style-type: none">The ptp priority2 command configures the priority2 value of 128 to use when advertising this clock. <pre>switch(config)# ptp priority2 128 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 272.</p>					
Command	Description																
ptp priority1	Configures the priority1 value to use when advertising this clock.																
ptp priority2	Configures the priority2 value to use when advertising this clock.																
show ptp brief	Displays the PTP status.																
show ptp clock	Displays the properties of the local clock.																

Copyright Registration Information	Cisco	Arista															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>ptp sync interval</p> <p>To configure the interval between Precision Time Protocol (PTP) synchronization messages on an interface, use the ptp sync interval command. To remove the interval configuration for PTP messages synchronization, use the no form of this command.</p> <pre>ptp sync interval seconds no ptp sync interval seconds</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.</p>	<p>Set the Peer Delay Request Interval</p> <p>To configure the minimum interval allowed between Precision Time Protocol (PTP) peer delay-request messages, use the ptp pdelay-req interval command.</p> <ul style="list-style-type: none"> The ptp pdelay-req interval command configures the minimum interval allowed between Precision Time Protocol (PTP) peer delay-request messages to 3. <pre>switch(config-if-Et5)# ptp pdelay-request interval 3 switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 273.</p>															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>ptp sync interval</p> <p>To configure the interval between Precision Time Protocol (PTP) synchronization messages on an interface, use the ptp sync interval command. To remove the interval configuration for PTP messages synchronization, use the no form of this command.</p> <pre>ptp sync interval seconds no ptp sync interval seconds</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.</p>	<p>ptp delay-req interval</p> <p>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp delay-req interval log_interval no ptp delay-req interval default ptp delay-req interval</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 318.</p>															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>ptp</td><td>Enables or disables PTP on an interface.</td></tr> <tr> <td></td><td>ptp announce</td><td>Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.</td></tr> <tr> <td></td><td>ptp delay-request minimum interval</td><td>Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.</td></tr> <tr> <td></td><td>ptp vlan vlan</td><td>Configures the PTP VLAN value on an interface.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 342.</p>	Related Commands	Command	Description		ptp	Enables or disables PTP on an interface.		ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.		ptp delay-request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.		ptp vlan vlan	Configures the PTP VLAN value on an interface.	<p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp delay-request interval 3 switch(config-if-Et5)#</pre> <ul style="list-style-type: none"> This command removes the configured minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp delay-request interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 318.</p>
Related Commands	Command	Description															
	ptp	Enables or disables PTP on an interface.															
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.															
	ptp delay-request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.															
	ptp vlan vlan	Configures the PTP VLAN value on an interface.															

Copyright Registration Information	Cisco	Arista															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Make sure that you have globally enabled PTP on the device and configured the source IP address for PTP communication.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 343.</p>	<p>The <code>ptp delay-req</code> interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the <code>no</code> form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 318.</p>															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td><code>ptp</code></td><td>Enables or disables PTP on an interface.</td></tr> <tr> <td></td><td><code>ptp announce</code></td><td>Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.</td></tr> <tr> <td></td><td><code>ptp delay-request minimum interval</code></td><td>Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.</td></tr> <tr> <td></td><td><code>ptp sync interval</code></td><td>Configures the interval between PTP synchronization messages on an interface.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 344.</p>	Related Commands	Command	Description		<code>ptp</code>	Enables or disables PTP on an interface.		<code>ptp announce</code>	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.		<code>ptp delay-request minimum interval</code>	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.		<code>ptp sync interval</code>	Configures the interval between PTP synchronization messages on an interface.	<p>ptp announce interval</p> <p>The <code>ptp announce interval</code> command configures the interval between PTP announcement messages on or the number of PTP intervals before a timeout occurs. To disable this feature, use the <code>no</code> form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp announce interval log_interval no ptp announce interval default ptp announce interval</pre> <p>Parameters</p> <ul style="list-style-type: none"> <code>log_interval</code> The number of log seconds between PTP announcement message (base 2 log (seconds)). Value ranges from 0 to 4; default value is 1. <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the interval between PTP announce messages on an interface. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp announce interval 1 switch(config-if-Et5)#</pre> <ul style="list-style-type: none"> This command removes the configured interval between PTP announce messages on interface Ethernet 5. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp announce interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 315.</p>
Related Commands	Command	Description															
	<code>ptp</code>	Enables or disables PTP on an interface.															
	<code>ptp announce</code>	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.															
	<code>ptp delay-request minimum interval</code>	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.															
	<code>ptp sync interval</code>	Configures the interval between PTP synchronization messages on an interface.															

Copyright Registration Information	Cisco	Arista																														
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>snmp-server user</p> <p>To configure the Simple Network Management Protocol (SNMP) user information, use the snmp-server user command. To disable the configuration or to revert to factory defaults, use the no form of this command.</p> <pre>snmp-server user username [group-name] [auth {md5 sha} password [priv {aes-128} password] [localizedkey] [engineID id]] no snmp-server user username [group-name] [auth {md5 sha} password [priv {aes-128} password] [localizedkey] [engineID id]]</pre> <table border="1"> <tr> <td>Syntax Description</td><td>username</td><td>Name of the user. The name can be any case-sensitive, alphanumeric string up to 32 characters.</td></tr> <tr> <td></td><td>group-name</td><td>(Optional) Name of the group. The name can be any case-sensitive, alphanumeric string up to 32 characters.</td></tr> <tr> <td></td><td>auth</td><td>(Optional) Sets authentication parameters for the user.</td></tr> <tr> <td></td><td>md5</td><td>Uses the MD5 algorithm for authentication.</td></tr> <tr> <td></td><td>sha</td><td>Uses the SHA algorithm for authentication.</td></tr> <tr> <td></td><td>password</td><td>User password. The password can be any case-sensitive, alphanumeric string up to 64 characters. If you configure the localizedkey keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters</td></tr> <tr> <td></td><td>priv</td><td>(Optional) Sets encryption parameters for the user.</td></tr> <tr> <td></td><td>aes-128</td><td>(Optional) Sets the 128-byte AES algorithm for privacy.</td></tr> <tr> <td></td><td>localizedkey</td><td>(Optional) Sets passwords in the localized key format. If you configure this keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters.</td></tr> <tr> <td></td><td>engineID id</td><td>(Optional) Configures the SNMP Engine ID for a notification target user. The engineID format is a 12-digit colon-separated decimal number.</td></tr> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 394.</p>	Syntax Description	username	Name of the user. The name can be any case-sensitive, alphanumeric string up to 32 characters.		group-name	(Optional) Name of the group. The name can be any case-sensitive, alphanumeric string up to 32 characters.		auth	(Optional) Sets authentication parameters for the user.		md5	Uses the MD5 algorithm for authentication.		sha	Uses the SHA algorithm for authentication.		password	User password. The password can be any case-sensitive, alphanumeric string up to 64 characters. If you configure the localizedkey keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters		priv	(Optional) Sets encryption parameters for the user.		aes-128	(Optional) Sets the 128-byte AES algorithm for privacy.		localizedkey	(Optional) Sets passwords in the localized key format. If you configure this keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters.		engineID id	(Optional) Configures the SNMP Engine ID for a notification target user. The engineID format is a 12-digit colon-separated decimal number.	<p>snmp-server user</p> <p>The snmp-server user command adds a user to a Simple Network Management Protocol (SNMP) group or modifies an existing user's parameters.</p> <p>To configure a remote user, specify the IP address or port number of the device where the user's remote SNMP agent resides. A remote agent's engine ID must be configured before remote users for that agent are configured. A user's authentication and privacy digests are derived from the engine ID and the user's password. The configuration command fails if the remote engine ID is not configured first.</p> <p>The no snmp-server user and default snmp-server user commands remove the user from an SNMP group by deleting the user command from <i>running-config</i>.</p> <p>Platform all Command Mode Global Configuration</p> <p>Command Syntax</p> <pre>snmp-server user user_name group_name [AGENT] VERSION [ENGINE] [SECURITY] no snmp-server user user_name group_name [AGENT] VERSION default snmp-server user user_name group_name [AGENT] VERSION</pre> <p>Parameters</p> <ul style="list-style-type: none"> user_name name of the user on the host that connects to the agent. group_name name of the group to which the user is associated. AGENT location of the host connecting to the SNMP agent. Configuration options include: <ul style="list-style-type: none"> <no parameter> local SNMP agent. remote_addr [udp-port p_num] remote SNMP agent location (IP address, udp port). <i>addr</i> denotes the IP address; <i>p_num</i> denotes the udp port socket. (default port is 162). VERSION SNMP version; options include: <ul style="list-style-type: none"> v1 SNMPv1. v2c SNMPv2c. v3 SNMPv3; enables user-name match authentication. ENGINE engine ID used to localize passwords. Available only if VERSION is v3. <ul style="list-style-type: none"> <no parameter> Passwords localized by SNMP copy specified by <i>agent</i>. localized engineID octet string of engineID. SECURITY Specifies authentication and encryption levels. Available only if VERSION is v3. Encryption is available only when authentication is configured. <ul style="list-style-type: none"> <no parameter> no authentication or encryption. auth a_meth a_pass [priv e_meth e_pass] authentication and encryption parameters. <ul style="list-style-type: none"> <i>a-meth</i> authentication method: options are md5 (HMAC-MD5-96) and sha (HMAC-SHA-96). <i>a-pass</i> authentication string for users receiving packets. <i>e-meth</i> encryption method: tions are aes (AES-128) and des (CBC-DES). <i>e-pass</i> encryption string for the users sending packets. <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 1999.</p>
Syntax Description	username	Name of the user. The name can be any case-sensitive, alphanumeric string up to 32 characters.																														
	group-name	(Optional) Name of the group. The name can be any case-sensitive, alphanumeric string up to 32 characters.																														
	auth	(Optional) Sets authentication parameters for the user.																														
	md5	Uses the MD5 algorithm for authentication.																														
	sha	Uses the SHA algorithm for authentication.																														
	password	User password. The password can be any case-sensitive, alphanumeric string up to 64 characters. If you configure the localizedkey keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters																														
	priv	(Optional) Sets encryption parameters for the user.																														
	aes-128	(Optional) Sets the 128-byte AES algorithm for privacy.																														
	localizedkey	(Optional) Sets passwords in the localized key format. If you configure this keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters.																														
	engineID id	(Optional) Configures the SNMP Engine ID for a notification target user. The engineID format is a 12-digit colon-separated decimal number.																														

Copyright Registration Information	Cisco	Arista									
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Examples</p> <p>This example shows how to display the EEE status on an interface:</p> <pre>switch# show interface ethernet2/6 Ethernet2/6 is down (Link not connected) admin state is up, Dedicated Interface Hardware: 10000 Ethernet, address: 0022.5579.de41 (bia 001b.54c1.af5d) MTU 1500 bytes, BW 10000000 Kbit, DLY 10 usec reliability 255/255, txload 1/255, rxload 1/255 Encapsulation ARPA, medium is broadcast auto-duplex, auto-speed, media type is 10G Beacon is turned off Auto-Negotiation is turned off Input flow-control is off, output flow-control is off Auto-mdix is turned off Rate mode is shared Switchport monitor is off EtherType is 0x8100 EEE (efficient-ethernet) : n/a Last link flapped never Last clearing of "show interface" counters never 0 interface resets 30 seconds input rate 0 bits/sec, 0 packets/sec 30 seconds output rate 0 bits/sec, 0 packets/sec Load-Interval #2: 5 minute (300 seconds)</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 514.</p>	<p>Example</p> <ul style="list-style-type: none"> This command assigns the MAC address of 001c.2804.17e1 to Ethernet interface 7, then displays interface parameters, including the assigned address. <pre>switch(config)#interface ethernet 7 switch(config-if-Et7)#mac-address 001c.2804.17e1 switch(config-if-Et7)#show interface ethernet 7 Ethernet3 is up, line protocol is up (connected) Hardware is Ethernet, address is 001c.2804.17e1 (bia 001c.7312.02e2) Description: b.e45 MTU 9212 bytes, BW 10000000 Kbit Full-duplex, 10Gb/s, auto negotiation: off Last clearing of "show interface" counters never 5 seconds input rate 7.84 kbps (0.0% with framing), 10 packets/sec 5 seconds output rate 270 kbps (0.0% with framing), 24 packets/sec 1363799 packets input, 222736140 bytes Received 0 broadcasts, 290904 multicast 0 runts, 0 giants 0 input errors, 0 CRC, 0 alignment, 0 symbol 0 PAUSE input 2264927 packets output, 2348747214 bytes Sent 0 broadcasts, 28573 multicast 0 output errors, 0 collisions 0 late collision, 0 deferred 0 PAUSE output switch(config-if-Et7)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 437.</p>									
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp tlv-select</td><td>Displays the LLDP TLV configuration.</td></tr> <tr> <td></td><td>lldp tlv-select</td><td>Specifies the TLVs to send and receive in LLDP packets.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 515.</p>	Related Commands	Command	Description		show lldp tlv-select	Displays the LLDP TLV configuration.		lldp tlv-select	Specifies the TLVs to send and receive in LLDP packets.	<p>lldp tlv-select</p> <p>The lldp tlv-select command allows the user to specify the TLVs to send and receive in LLDP packets. The available TLVs are management-address, port-description, port-vlan, system-capabilities, system-description, and system-name.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 592.</p>
Related Commands	Command	Description									
	show lldp tlv-select	Displays the LLDP TLV configuration.									
	lldp tlv-select	Specifies the TLVs to send and receive in LLDP packets.									

Copyright Registration Information	Cisco	Arista															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp traffic interface ethernet</td><td>Displays the number of LLDP packets sent and received on the interface.</td></tr> <tr> <td></td><td>show running-config lldp</td><td>Displays the global LLDP configuration.</td></tr> <tr> <td></td><td>lldp transmit</td><td>Enables the transmission of LLDP packets on an interface.</td></tr> <tr> <td></td><td>lldp receive</td><td>Enables the reception of LLDP packets on an interface.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.</p>	Related Commands	Command	Description		show lldp traffic interface ethernet	Displays the number of LLDP packets sent and received on the interface.		show running-config lldp	Displays the global LLDP configuration.		lldp transmit	Enables the transmission of LLDP packets on an interface.		lldp receive	Enables the reception of LLDP packets on an interface.	<p>lldp transmit</p> <p>The lldp transmit command enables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 593.</p>
Related Commands	Command	Description															
	show lldp traffic interface ethernet	Displays the number of LLDP packets sent and received on the interface.															
	show running-config lldp	Displays the global LLDP configuration.															
	lldp transmit	Enables the transmission of LLDP packets on an interface.															
	lldp receive	Enables the reception of LLDP packets on an interface.															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp holdtime</td><td>Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.</td></tr> <tr> <td></td><td>lldp reinit</td><td>Specifies the delay time in seconds for LLDP to initialize on any interface.</td></tr> <tr> <td></td><td>lldp timer</td><td>Specifies the transmission frequency of LLDP updates in seconds.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.</p>	Related Commands	Command	Description		show lldp holdtime	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.		lldp reinit	Specifies the delay time in seconds for LLDP to initialize on any interface.		lldp timer	Specifies the transmission frequency of LLDP updates in seconds.	<p>12.3.3.2 Setting the LLDP Hold Time</p> <p>The lldp holdtime command specifies the amount of time in seconds that a receiving device should hold the information sent by the device before discarding it.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 578.</p>			
Related Commands	Command	Description															
	show lldp holdtime	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.															
	lldp reinit	Specifies the delay time in seconds for LLDP to initialize on any interface.															
	lldp timer	Specifies the transmission frequency of LLDP updates in seconds.															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp holdtime</td><td>Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.</td></tr> <tr> <td></td><td>lldp reinit</td><td>Specifies the delay time in seconds for LLDP to initialize on any interface.</td></tr> <tr> <td></td><td>lldp timer</td><td>Specifies the transmission frequency of LLDP updates in seconds.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.</p>	Related Commands	Command	Description		show lldp holdtime	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.		lldp reinit	Specifies the delay time in seconds for LLDP to initialize on any interface.		lldp timer	Specifies the transmission frequency of LLDP updates in seconds.	<p>lldp reinit</p> <p>The lldp reinit command specifies the delay time in seconds for LLDP to initialize on any interface.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 589.</p>			
Related Commands	Command	Description															
	show lldp holdtime	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.															
	lldp reinit	Specifies the delay time in seconds for LLDP to initialize on any interface.															
	lldp timer	Specifies the transmission frequency of LLDP updates in seconds.															

Copyright Registration Information	Cisco	Arista									
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp traffic interface ethernet</td><td>Displays the number of LLDP packets sent and received on the interface.</td></tr> <tr> <td></td><td>show running-config lldp</td><td>Displays the global LLDP configuration.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 527.</p>	Related Commands	Command	Description		show lldp traffic interface ethernet	Displays the number of LLDP packets sent and received on the interface.		show running-config lldp	Displays the global LLDP configuration.	<p>show lldp traffic</p> <p>The show lldp traffic command displays LLDP counters, including the number of packets sent and received, and the number of packets discarded.</p> <p>Platform all Command Mode EXEC</p> <p>Command Syntax</p> <p>show lldp traffic [INTERFACE]</p> <p>Parameters</p> <ul style="list-style-type: none"> • INTERFACE Interface type and numbers. Options include: <ul style="list-style-type: none"> — <no parameter> Display information for all interfaces. — ethernet e_range Ethernet interface range specified by e_range. — management m_range Management interface range specified by m_range. Valid e_range and m_range formats include number, number range, or comma-delimited list of numbers and ranges. <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 599.</p>
Related Commands	Command	Description									
	show lldp traffic interface ethernet	Displays the number of LLDP packets sent and received on the interface.									
	show running-config lldp	Displays the global LLDP configuration.									
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>show lldp traffic</td><td>Displays the LLDP counters, including the number of LLDP packets sent and received by the device, the number of discarded packets, and the number of unrecognized TLVs.</td></tr> <tr> <td></td><td>show running-config lldp</td><td>Displays the global LLDP configuration.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 529.</p>	Related Commands	Command	Description		show lldp traffic	Displays the LLDP counters, including the number of LLDP packets sent and received by the device, the number of discarded packets, and the number of unrecognized TLVs.		show running-config lldp	Displays the global LLDP configuration.	<p>show lldp traffic</p> <p>The show lldp traffic command displays LLDP counters, including the number of packets sent and received, and the number of packets discarded.</p> <p>Platform all Command Mode EXEC</p> <p>Command Syntax</p> <p>show lldp traffic [INTERFACE]</p> <p>Parameters</p> <ul style="list-style-type: none"> • INTERFACE Interface type and numbers. Options include: <ul style="list-style-type: none"> — <no parameter> Display information for all interfaces. — ethernet e_range Ethernet interface range specified by e_range. — management m_range Management interface range specified by m_range. Valid e_range and m_range formats include number, number range, or comma-delimited list of numbers and ranges. <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 599.</p>
Related Commands	Command	Description									
	show lldp traffic	Displays the LLDP counters, including the number of LLDP packets sent and received by the device, the number of discarded packets, and the number of unrecognized TLVs.									
	show running-config lldp	Displays the global LLDP configuration.									

Copyright Registration Information	Cisco	Arista				
<div>Cisco NX-OS 6.2</div> <div>Effective date of registration: 11/13/2014</div>	<div><div>show ptp clock</div><div>To display the Precision Time Protocol (PTP) clock information, use the show ptp clock command.</div><div>show ptp clock</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>Supported User Roles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display the PTP clock information:</div><div>switch# show ptp clock PTP Device Type: Boundary clock Clock Identity: 0:18:ba:ff:ff:d8: e:17 Clock Domain: 0 Number of PTP ports: 2 Priority1: 255 Priority2: 255 Clock Quality: Class: 248 Accuracy: 254 Offset (log variance): 65535 Offset From Master: 0 Mean Path Delay: 0 Steps removed: 1 Local clock time: Sun Jan 15 20:57:29 2011</div></div></div> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 601.</div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>Show PTP Clock and Offset</div><div>To display the Precision Time Protocol (PTP) local clock and offset, use the show ptp clock command.</div><div><ul style="list-style-type: none">The show ptp clock command displays the Precision Time Protocol (PTP) local clock and offset.</div><div>switch# show ptp clock PTP Mode: Boundary Clock Clock Identity: 0x00:1c:73:ff:ff:1e:83:24 Clock Domain: 1 Number of PTP ports: 24 Priority1: 128 Priority2: 128 Clock Quality: Class: 248 Accuracy: 0x30 Offset Scaled Log Variance: 0xffff Offset From Master: 0 Mean Path Delay: 0 Steps Removed: 0 switch#</div><div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 275.</div></div>
	Release	Modification				
5.2(1)	This command was introduced.					

Copyright Registration Information	Cisco	Arista																																		
<div>Cisco NX-OS 6.2</div> <div>Effective date of registration: 11/13/2014</div>	<div><div>show ptp clock foreign-masters-record</div><div>To display information about the state of foreign masters known to the Precision Time Protocol (PTP) process, use the show ptp clocks foreign-masters-record command.</div><div>show ptp clock foreign-masters-record {interface [ethernet]}</div><div><table><tr><td>Syntax Description</td><td>interface</td><td>Specifies an interface.</td></tr><tr><td></td><td>ethernet</td><td>(Optional) Specifies an Ethernet interface.</td></tr></table></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>Supported User Roles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display information about the state of foreign masters known to the PTP process:</div><div>switch# show ptp clock foreign-masters-record interface ethernet 7/1 RP/0/0/CPU0:demo#show ptp clocks foreign-masters P1=Priority1, P2=Priority2, C=Class, A=Accuracy, OSLV=Offset-Scaled-Log-Variance, SR=Steps-Removed GM=Is grandmaster</div><div><table><tr><th>Interface</th><th>Clock-ID</th><th>P1</th><th>P2</th><th>C</th><th>A</th><th>OSLV</th><th>SR</th></tr><tr><td>Eth7/10</td><td>0:18:ba:ff:ff:d8: e:16 255 255</td><td>248</td><td>254</td><td>65535</td><td>0</td><td></td><td>GM</td></tr><tr><td>Eth7/1</td><td>0:18:ba:ff:ff:d8: e:16 255 255</td><td>248</td><td>254</td><td>65535</td><td>0</td><td></td><td>GM</td></tr></table></div></div></div> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 603.</div>	Syntax Description	interface	Specifies an interface.		ethernet	(Optional) Specifies an Ethernet interface.	Release	Modification	5.2(1)	This command was introduced.	Interface	Clock-ID	P1	P2	C	A	OSLV	SR	Eth7/10	0:18:ba:ff:ff:d8: e:16 255 255	248	254	65535	0		GM	Eth7/1	0:18:ba:ff:ff:d8: e:16 255 255	248	254	65535	0		GM	<div><div>Show PTP Foreign Master</div><div>To display information about the state of foreign masters known to the Precision Time Protocol (PTP) process, use the show ptp foreign-master-record command.</div><div><ul style="list-style-type: none">The show ptp foreign-master-records command displays information about the state of foreign masters known to the PTP process.</div><div>switch# show ptp clocks foreign-masters-record No Foreign Master Records switch#</div><div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 277.</div></div>
	Syntax Description	interface	Specifies an interface.																																	
	ethernet	(Optional) Specifies an Ethernet interface.																																		
Release	Modification																																			
5.2(1)	This command was introduced.																																			
Interface	Clock-ID	P1	P2	C	A	OSLV	SR																													
Eth7/10	0:18:ba:ff:ff:d8: e:16 255 255	248	254	65535	0		GM																													
Eth7/1	0:18:ba:ff:ff:d8: e:16 255 255	248	254	65535	0		GM																													

Copyright Registration Information	Cisco	Arista																								
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div>Examples</div> <div>This example shows how to display information about the state of foreign masters known to the PTP process:</div> <div>switch# show ptp clock foreign-masters-record interface ethernet 7/1 RP/0/0/CPU0:demo#show ptp clocks foreign-masters P1=Priority1, P2=Priority2, C=Class, A=Accuracy, OSLV=Offset-Scaled-Log-Variance, SR=Steps-Removed GM=Is grandmaster</div> <table><thead><tr><th>Interface</th><th>Clock-ID</th><th>P1</th><th>P2</th><th>C</th><th>A</th><th>OSLV</th><th>SR</th></tr></thead><tbody><tr><td>Eth7/10</td><td>0:18:ba:ff:ff:d8: e:16 255 255</td><td>248</td><td>254</td><td>254</td><td>65535</td><td>0</td><td>GM</td></tr><tr><td>Eth7/1</td><td>0:18:ba:ff:ff:d8: e:16 255 255</td><td>248</td><td>254</td><td>254</td><td>65535</td><td>0</td><td>GM</td></tr></tbody></table> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 603.</div>	Interface	Clock-ID	P1	P2	C	A	OSLV	SR	Eth7/10	0:18:ba:ff:ff:d8: e:16 255 255	248	254	254	65535	0	GM	Eth7/1	0:18:ba:ff:ff:d8: e:16 255 255	248	254	254	65535	0	GM	<div>Examples</div> <div><ul style="list-style-type: none">This command shows how to display information about the state of foreign masters known to the PTP process.</div> <div>switch# show ptp clocks foreign-masters-record No Foreign Master Records switch#</div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 349.</div>
Interface	Clock-ID	P1	P2	C	A	OSLV	SR																			
Eth7/10	0:18:ba:ff:ff:d8: e:16 255 255	248	254	254	65535	0	GM																			
Eth7/1	0:18:ba:ff:ff:d8: e:16 255 255	248	254	254	65535	0	GM																			

Copyright Registration Information	Cisco	Arista	
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div>show ptp parent</div> <div>To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the show ptp parent command.</div> <div>show ptp parent</div> <div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div> <div><div>Defaults</div><div>None</div></div> <div><div>Command Modes</div><div>Any command mode</div></div> <div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div> <div><div>Command History</div><div><div>Release</div><div>Modification</div><div>5.2(1)</div><div>This command was introduced.</div></div></div> <div><div>Usage Guidelines</div><div>This command does not require a license.</div></div> <div><div>Examples</div><div><div>This example shows how to display information about the parent and grand master of the PTP clock:</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0:18:ba:ff:ff:d8: e:16 Parent Port Number: 1546 Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0:18:ba:ff:ff:d8: e:16 Grandmaster Clock Quality: Class: 248 Accuracy: 254 Offset (log variance): 65535 Priority1: 255 Priority2: 255</div></div></div>	<div>Show PTP Parent Information</div> <div>To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the show ptp parent command.</div> <div><div>The show ptp parent command displays information about the parent and grand master of the Precision Time Protocol (PTP) clock.</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Parent Port Number: 0 Parent IP Address: N/A Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Grandmaster Clock Quality: Class: 248 Accuracy: 0x30 Offset Scaled Log Variance: 0xffff Priority1: 128 Priority2: 128 switch#</div></div>	Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 275.

Copyright Registration Information	Cisco	Arista				
<div>Cisco NX-OS 6.2</div> <div>Effective date of registration: 11/13/2014</div>	<div><div>show ptp parent</div><div>To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the show ptp parent command.</div><div>show ptp parent</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display information about the parent and grand master of the PTP clock:</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0:18:ba:ff:ff:d8: e:16 Parent Port Number: 1546 Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0:18:ba:ff:ff:d8: e:16 Grandmaster Clock Quality: Class: 248 Accuracy: 254 Offset (log variance): 65535 Priority1: 255 Priority2: 255</div></div></div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>show ptp parent</div><div>The show ptp parent command displays information about the parent and grand master of the Precision Time Protocol (PTP) clock.</div><div>Platform Arad, FM6000 Command Mode Privileged EXEC</div><div><div>Command Syntax</div><div>show ptp parent</div></div><div><div>Examples</div><div><div><ul style="list-style-type: none">This command shows how to display information about the parent and master of the PTP clock.</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Parent Port Number: 0 Parent IP Address: N/A Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Grandmaster Clock Quality: Class: 248 Accuracy: 0x30 Offset Scaled Log Variance: 0xffff Priority1: 128 Priority2: 128 switch#</div></div></div></div>
	Release	Modification				
5.2(1)	This command was introduced.					

Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 352.

Copyright Registration Information	Cisco	Arista				
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div><div>show ptp time-property</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div>show ptp time-property</div></div> <div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div> <div><div>Defaults</div><div>None</div></div> <div><div>Command Modes</div><div>Any command mode</div></div> <div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div> <div><div>Command History</div><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div> <div><div>Usage Guidelines</div><div>This command does not require a license.</div></div> <div><div>Examples</div><div>This example shows how to display the PTP clock properties: switch# show ptp time-property PTP CLOCK TIME PROPERTY: Current UTC Offset valid: 0 Current UTC Offset: 33 Leap59: 0 Leap61: 0 Time Traceable: 0 Frequency Traceable: 0 PTP Timescale: 0 Time Source: 0xA0 (internal Oscillator)</div></div> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 611.</div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>Show PTP Clock Properties</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div><ul style="list-style-type: none">The show ptp time-property command displays the Precision Time Protocol (PTP) clock properties. switch# show ptp time-property Current UTC offset valid: False Current UTC offset: 0 Leap 59: False Leap 61: False Time Traceable: False Frequency Traceable: False PTP Timescale: False Time Source: 0x0 switch#</div></div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 275-76.</div>
	Release	Modification				
5.2(1)	This command was introduced.					

Copyright Registration Information	Cisco	Arista					
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div><div>show ptp time-property</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div>show ptp time-property</div><div>Syntax Description<div>This command has no arguments or keywords.</div></div><div>Defaults<div>None</div></div><div>Command Modes<div>Any command mode</div></div><div>SupportedUserRoles<div>network-admin network-operator vdc-admin vdc-operator</div></div><div>Command History<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div><div>Usage Guidelines<div>This command does not require a license.</div></div><div>Examples<div>This example shows how to display the PTP clock properties:</div><div>switch# show ptp time-property PTP CLOCK TIME PROPERTY: Current UTC Offset valid: 0 Current UTC Offset: 33 Leap59: 0 Leap61: 0 Time Traceable: 0 Frequency Traceable: 0 PTP Timescale: 0 Time Source: 0xA0 (internal Oscillator)</div></div></div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>show ptp time-property</div><div>The show ptp time-property command displays the Precision Time Protocol (PTP) clock properties.</div><div>Platform<div>Arad, FM6000</div></div><div>Command Mode<div>Privileged EXEC</div></div><div>Command Syntax<div>show ptp time-property</div></div><div>Examples<div><div>This command shows the PTP clock properties.</div><div>switch# show ptp time-property Current UTC offset valid: False Current UTC offset: 0 Leap 59: False Leap 61: False Time Traceable: False Frequency Traceable: False PTP Timescale: False Time Source: 0x0 switch#</div></div></div></div>	<div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 354.</div>
	Release	Modification					
5.2(1)	This command was introduced.						

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Examples</p> <p>This example shows how to display the SNMP information:</p> <pre>switch(config)# show snmp sys contact: sys location: anyplace, Anywhere 0 SNMP packets input 0 Bad SNMP versions 0 Unknown community name 0 illegal operation for community name supplied 0 Encoding errors 0 Number of requested variables 0 Number of altered variables 0 Get-request PDUs 0 Get-next PDUs 0 Set-request PDUs 0 SNMP packets output 0 Too big errors 0 No such name errors 0 Bad values errors 0 General errors</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 634.</p>	<p>Example</p> <ul style="list-style-type: none"> This command configures <i>xyz-1234</i> as the chassis-ID string, then displays the result. <pre>switch(config)#snmp-server chassis-id xyz-1234 switch(config)#show snmp Chassis: xyz-1234 <---chassis ID</pre> <pre>8 SNMP packets input 0 Bad SNMP version errors 0 Unknown community name 0 Illegal operation for community name supplied 0 Encoding errors 8 Number of requested variables 0 Number of altered variables 4 Get-request PDUs 4 Get-next PDUs 0 Set-request PDUs 21 SNMP packets output 0 Too big errors 0 No such name errors 0 Bad value errors 0 General errors 8 Response PDUs 0 Trap PDUs SNMP logging: enabled Logging to taccon.162 SNMP agent enabled switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 354.</p>

Copyright Registration Information	Cisco	Arista								
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div><div>show snmp engineID</div><div>To display the Simple Network Management Protocol (SNMP) engine ID, use the show snmp engineID command.</div><div>show snmp engineID</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>Supported User Roles</div><div>network-admin network-operator vdc admin vdc-operator</div></div><div><div>Command History</div><table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>4.0(1)</td><td>This command was introduced.</td></tr></tbody></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display the SNMP engine ID:</div><div>switch(config)# show snmp engineID Local SNMP engineID: [Hex] 8000000030005300A0B0C [Dec] 128.000.000.009.000.000.005.048.010.011.012</div></div><div><div>Related Commands</div><table><thead><tr><th>Command</th><th>Description</th></tr></thead><tbody><tr><td>snmp-server user</td><td>Configures SNMP target notification users.</td></tr></tbody></table></div></div>	Release	Modification	4.0(1)	This command was introduced.	Command	Description	snmp-server user	Configures SNMP target notification users.	<div><div>show snmp engineID</div><div>The show snmp engineID command displays the identification of the local Simple Network Management Protocol (SNMP) engine and of all remote engines that are configured on the switch.</div><div>Platformall Command ModeEXEC</div><div><div>Command Syntax</div><div>show snmp engineID</div></div><div><div>Example</div><div><ul style="list-style-type: none">This command displays the ID of the local SNMP engine.</div><div>switch>show snmp engineID Local SNMP EngineID: f5717f001c730436d700 switch></div></div></div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 1978.</div>
	Release	Modification								
4.0(1)	This command was introduced.									
Command	Description									
snmp-server user	Configures SNMP target notification users.									

Copyright Registration Information	Cisco	Arista
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>Precision Time Protocol</p> <p>The Precision Time Protocol (PTP) is a time synchronization protocol for nodes distributed across a network. Its hardware timestamp feature provides greater accuracy than other time synchronization protocols such as Network Time Protocol (NTP). For more information about PTP, see Chapter 4, "Configuring PTP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-3.</p>	<p>5.3.2 Precision Time Protocol (PTP)</p> <p>The Precision Time Protocol (PTP) can substantially enhance the accuracy of real-time clocks in networked devices by providing sub-microsecond clock synchronization. Inbound clock signals are organized into a master-slave hierarchy. PTP identifies the switch port that is connected to the device with the most precise clock. This clock is referred to as the master clock. All the other devices on the network synchronize their clocks with the master and are referred to as slaves.</p> <p>The master clock sends out a sync message every second. The slave clock sends a delay request message to the master clock noting the time it was sent in order to measure and eliminate packet delays. The master clock then replies with the time stamp the delay message was received. The slave clock then computes the master clock time compensated for delays and finalizes synchronization. Constantly exchanged timing messages ensure continued synchronization.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 270.</p>
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>SNMP</p> <p>The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network. For more information, see Chapter 11, "Configuring SNMP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-5.</p>	<p>37.2 SNMP Conceptual Overview</p> <p>Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a standardized framework and a common language to monitor and manage network devices.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 1961.</p>
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>SNMP</p> <p>The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network. For more information, see Chapter 11, "Configuring SNMP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-5.</p>	<p>Chapter 37 SNMP</p> <p>SNMP is an application-layer protocol that provides a standardized framework and a common language to monitor and manage network devices.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 43.</p>

Copyright Registration Information	Cisco	Arista				
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>Configuring the NTP Source IP Address</p> <p>NTP sets the source IP address for all NTP packets based on the address of the interface through which the NTP packets are sent. You can configure NTP to use a specific source IP address.</p> <p>To configure the NTP source IP address, use the following command in global configuration mode:</p> <table><tr><th>Command</th><th>Purpose</th></tr><tr><td>[no] ntp source ip-address</td><td>Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.</td></tr></table> <p>Example: switch(config)# ntp source 192.0.2.1</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 3-16.</p>	Command	Purpose	[no] ntp source ip-address	Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.	<p>Configure the Source IP</p> <p>To configure the source IP address for all PTP packets, use the ptp source ip command.</p> <ul style="list-style-type: none">The ptp source ip command configures the source IP address of 10.0.2.1 for all PTP packets <pre>switch(config)# ptp source ip 10.0.2.1 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 272.</p>
Command	Purpose					
[no] ntp source ip-address	Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.					
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>Configuration Examples for NTP</p> <p>This example shows how to configure an NTP server and peer, enable NTP authentication, enable NTP logging, and then save the configuration in startup so that it is saved across reboots and restarts:</p> <pre>switch# config t Enter configuration commands, one per line. End with CNTL/Z. switch(config)# ntp server 192.0.2.105 key 42 switch(config)# ntp peer 2001:db8::4101 switch(config)# show ntp peers ----- Peer IP Address Serv/Peer ----- 2001:db8::4101 Peer (configured) 192.0.2.105 Server (configured) switch(config)# ntp authentication-key 42 md5 aNiceKey switch(config)# show ntp authentication-keys ----- Auth key MD5 String ----- 42 aNicekey switch(config)# ntp trusted-key 42 switch(config)# show ntp trusted-keys Trusted Keys: 42 switch(config)# ntp authenticate switch(config)# show ntp authentication-status Authentication enabled. switch(config)# ntp logging switch(config)# show ntp logging NTP logging enabled. switch(config)# copy running-config startup-config [#####] 100% switch(config)#</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 3-25.</p>	<p>Example</p> <ul style="list-style-type: none">These commands configure the switch to authenticate NTP packets using key 328 with the plaintext password "timeSync." <pre>switch(config)# ntp authentication-key 328 md5 timeSync switch(config)# ntp trusted key 328 switch(config)# ntp authenticate switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 270.</p>				

Copyright Registration Information	Cisco		Arista
	<div>Step 4</div> <div>[no] ptp domain number</div> <div>Example: switch(config)# ptp domain 1</div>	(Optional) Configures the domain number to use for this clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. The range is from 0 to 128.	<div>ptp domain</div> <p>The ptp domain command configures the domain number to use for the clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. To remove PTP settings, use the no form of this command.</p> <div>PlatformArad, FM6000</div> <div>Command ModeGlobal Configuration</div> <div>Command Syntax</div> <div>ptp domain domain_number</div> <div>no ptp domain</div> <div>default ptp domain</div> <div>Parameters</div> <div><ul style="list-style-type: none">domain_number The domain number to use for the clock. Value ranges from 0 to 255.</div> <div>Examples</div> <div><ul style="list-style-type: none">This command shows how to configure domain 1 for use with a clock.<div>switch(config)# ptp domain 1</div>switch(config)#This command removes the configured domain 1 for use with a clock.<div>switch(config)# no ptp domain 1</div>switch(config)#</div>
	<div>Step 5</div> <div>[no] ptp priority1 value</div> <div>Example: switch(config)# ptp priority1 10</div>	(Optional) Configures the priority1 value to use when advertising this clock. This value overrides the default criteria (clock quality, clock class, and so on) for best master clock selection. Lower values take precedence. The range is from 0 to 255.	
	<div>Step 6</div> <div>[no] ptp priority2 value</div> <div>Example: switch(config)# ptp priority2 20</div>	(Optional) Configures the priority2 value to use when advertising this clock. This value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255.	
Cisco NX-OS 6.2	Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-6.		
Effective date of registration: 11/13/2014	Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 319.		

Copyright Registration Information	Cisco		Arista
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<p>Step 4</p> <p>[no] ptp domain <i>number</i></p> <p>Example: switch(config)# ptp domain 1</p>	(Optional) Configures the domain number to use for this clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. The range is from 0 to 128.	<p>ptp priority1</p> <p>The ptp priority1 command configures the priority1 value to use when advertising the clock. This value overrides the default criteria for best master clock selection. Lower values take precedence. The range is from 0 to 255. To remove PTP settings, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Global Configuration</p> <p>Command Syntax</p> <p>ptp priority1 <i>priority_rate</i> no ptp priority1 default ptp priority1</p> <p>Parameters</p> <ul style="list-style-type: none"><i>priority_rate</i> The value to override the default criteria (clock quality, clock class, etc.) for best master clock selection. Lower values take precedence. Value ranges from 0 to 255. The default is 128. <p>Examples</p> <ul style="list-style-type: none">This command configures the preference level for a clock; slave devices use the priority1 value when selecting a master clock. <p>switch(config)# ptp priority1 120 switch(config)#</p> <ul style="list-style-type: none">This command removes the configured the preference level for a clock. <p>switch(config)# no ptp priority1 switch(config)#</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 326.</p>
	<p>Step 5</p> <p>[no] ptp priority1 <i>value</i></p> <p>Example: switch(config)# ptp priority1 10</p>	(Optional) Configures the priority1 value to use when advertising this clock. This value overrides the default criteria (clock quality, clock class, and so on) for best master clock selection. Lower values take precedence. The range is from 0 to 255.	
	<p>Step 6</p> <p>[no] ptp priority2 <i>value</i></p> <p>Example: switch(config)# ptp priority2 20</p>	(Optional) Configures the priority2 value to use when advertising this clock. This value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255.	
	<p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-6.</p>		

Copyright Registration Information	Cisco		Arista
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div>Step 4</div> <div>[no] ptp domain <i>number</i></div> <div>Example: switch(config)# ptp domain 1</div>	(Optional) Configures the domain number to use for this clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. The range is from 0 to 128.	<div>ptp priority2</div> <div>The ptp priority2 command configures the priority2 value to use when advertising this clock. This value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255. To remove PTP settings, use the no form of this command.</div> <div>Platform Arad, FM6000 Command Mode Global Configuration</div> <div>Command Syntax</div> <div>ptp priority2 <i>priority_rate</i> no ptp priority2 default ptp priority2</div> <div>Parameters</div> <div><ul style="list-style-type: none"><i>priority_rate</i> Sets a secondary preference level for a clock; slave devices use the priority2 value when selecting a master clock. Value ranges from 0 to 255.</div> <div>Examples</div> <div><ul style="list-style-type: none">This command sets a secondary preference level for a clock to 128.<div>switch(config)# ptp priority2 128 switch(config)#</div>This command removes the secondary preference level for a clock.<div>switch(config)# no ptp priority2 switch(config)#</div></div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 327.</div>
	<div>Step 5</div> <div>[no] ptp priority1 <i>value</i></div> <div>Example: switch(config)# ptp priority1 10</div>	(Optional) Configures the priority1 value to use when advertising this clock. This value overrides the default criteria (clock quality, clock class, and so on) for best master clock selection. Lower values take precedence. The range is from 0 to 255.	
	<div>Step 6</div> <div>[no] ptp priority2 <i>value</i></div> <div>Example: switch(config)# ptp priority2 20</div>	(Optional) Configures the priority2 value to use when advertising this clock. This value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255.	
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div>BEFORE YOU BEGIN</div> <div>Make sure that you are in the correct VDC. To change the VDC, use the switchto vdc command. Make sure that you have globally enabled PTP on the device and configured the source IP address for PTP communication.</div> <div>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-7.</div>		<div>ptp delay-req interval</div> <div>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 318.</div>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 4 <code>[no] ptp announce {interval seconds timeout count}</code></p> <p>Example: <pre>switch(config-if)# ptp announce interval 1</pre> </p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-8.</p> <p>(Optional) Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.</p> <p>The range for the PTP announcement interval is from 0 to 4 seconds, and the range for the interval timeout is from 2 to 10.</p>	<p>ptp announce interval</p> <p>The <code>ptp announce interval</code> command configures the interval between PTP announcement messages on or the number of PTP intervals before a timeout occurs. To disable this feature, use the <code>no</code> form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp announce interval log_interval no ptp announce interval default ptp announce interval</pre> <p>Parameters</p> <ul style="list-style-type: none"> <code>log_interval</code> The number of log seconds between PTP announcement message (base 2 log (seconds)). Value ranges from 0 to 4; default value is 1. <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the interval between PTP announce messages on an interface. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp announce interval 1 switch(config-if-Et5)#</pre> This command removes the configured interval between PTP announce messages on interface Ethernet 5. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp announce interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 315.</p>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 5 [no] ptp delay-request minimum interval seconds</p> <p>(Optional) Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state. The range is from -1 to 6 seconds.</p> <p>Example: switch(config-if)# ptp delay-request minimum interval 3</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-8.</p>	<p>ptp delay-req interval</p> <p>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp delay-req interval log_interval no ptp delay-req interval default ptp delay-req interval</pre> <p>Parameters</p> <ul style="list-style-type: none"> log_interval The range is -1 second to 8 seconds. The default is 5 log(seconds). <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp delay-request interval 3 switch(config-if-Et5)#</pre> This command removes the configured minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp delay-request interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 318.</p>

Copyright Registration Information	Cisco	Arista																
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<h3>Verifying the PTP Configuration</h3> <p>To display the PTP configuration, perform one of the following tasks:</p> <table><thead><tr><th>Command</th><th>Purpose</th></tr></thead><tbody><tr><td>show ptp brief</td><td>Displays the PTP status.</td></tr><tr><td>show ptp clock</td><td>Displays the properties of the local clock.</td></tr><tr><td>show ptp clock foreign-masters record [interface interface slot/port]</td><td>Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.</td></tr><tr><td>show ptp corrections</td><td>Displays the last few PTP corrections.</td></tr><tr><td>show ptp parent</td><td>Displays the properties of the PTP parent.</td></tr><tr><td>show ptp port interface interface slot/port</td><td>Displays the status of the PTP port.</td></tr><tr><td>show ptp time-property</td><td>Displays the properties of the PTP clock.</td></tr></tbody></table> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-9.</p>	Command	Purpose	show ptp brief	Displays the PTP status.	show ptp clock	Displays the properties of the local clock.	show ptp clock foreign-masters record [interface interface slot/port]	Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.	show ptp corrections	Displays the last few PTP corrections.	show ptp parent	Displays the properties of the PTP parent.	show ptp port interface interface slot/port	Displays the status of the PTP port.	show ptp time-property	Displays the properties of the PTP clock.	<h3>show ptp foreign-master-record</h3> <p>The show ptp foreign-master-record command displays information about the state of foreign masters known to the Precision Time Protocol (PTP) process.</p> <p>Platform Arad, FM6000 Command Mode EXEC</p> <h4>Command Syntax</h4> <pre>show ptp foreign-master-record</pre> <h4>Examples</h4> <ul style="list-style-type: none">This command shows how to display information about the state of foreign masters known to the PTP process. <pre>switch# show ptp clocks foreign-masters-record No Foreign Master Records switch#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 349.</p>
Command	Purpose																	
show ptp brief	Displays the PTP status.																	
show ptp clock	Displays the properties of the local clock.																	
show ptp clock foreign-masters record [interface interface slot/port]	Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.																	
show ptp corrections	Displays the last few PTP corrections.																	
show ptp parent	Displays the properties of the PTP parent.																	
show ptp port interface interface slot/port	Displays the status of the PTP port.																	
show ptp time-property	Displays the properties of the PTP clock.																	
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<h3>SNMP Functional Overview</h3> <p>The SNMP framework consists of three parts:</p> <ul style="list-style-type: none">An SNMP manager—The system used to control and monitor the activities of network devices using SNMP.An SNMP agent—The software component within the managed device that maintains the data for the device and reports these data, as needed, to managing systems. Cisco NX-OS supports the agent and MIB. To enable the SNMP agent, you must define the relationship between the manager and the agent.A managed information base (MIB)—The collection of managed objects on the SNMP agent. <p>SNMP is defined in RFCs 3411 to 3418.</p> <p>Cisco NX-OS supports SNMPv1, SNMPv2c, and SNMPv3. Both SNMPv1 and SNMPv2c use a community-based form of security.</p> <p>Cisco NX-OS supports SNMP over IPv6.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 11-2.</p>	<h3>37.2.3 SNMP Versions</h3> <p>Arista switches support the following SNMP versions:</p> <ul style="list-style-type: none">SNMPv1: The Simple Network Management Protocol, defined in RFC 1157. Security is based on community strings.SNMPv2c: Community-string based Administrative Framework for SNMPv2, defined in RFC 1901 RFC 1905, and RFC 1906. SNMPv2c uses the community-based security model of SNMPv1.SNMPv3: Version 3 is an interoperable standards-based protocol defined in RFCs 2273 to 2275. SNMPv3 provides secure access to devices by authenticating and encrypting packets. <p>The security features provided in SNMPv3 are as follows:</p> <ul style="list-style-type: none">Message integrity: Ensures packets are not tampered with in transit.Authentication: Determines the message is received from a valid source.Encryption: Scrambling packet contents to prevent an unauthorized source from learning it. <p>Both SNMPv1 and SNMPv2c use a community-based form of security. The community of managers able to access the agent MIB is controlled by a password.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 349.</p>																

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>SNMPv3</p> <p>SNMPv3 provides secure access to devices by a combination of authenticating and encrypting frames over the network. The security features provided in SNMPv3 are as follows:</p> <ul style="list-style-type: none"> • Message integrity—Ensures that a packet has not been tampered with while it was in-transit. • Authentication—Determines that the message is from a valid source. • Encryption—Scrambles the packet contents to prevent it from being seen by unauthorized sources. <p>SNMPv3 provides for both security models and security levels. A security model is an authentication strategy that is set up for a user and the role in which the user resides. A security level is the permitted level of security within a security model. A combination of a security model and a security level determines which security mechanism is employed when handling an SNMP packet.</p> <p>This section includes the following topics:</p> <ul style="list-style-type: none"> • Security Models and Levels for SNMPv1, v2, v3, page 11-4 • User-Based Security Model, page 11-5 • CLI and SNMP User Synchronization, page 11-5 <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 11-3.</p>	<p>37.2.3 SNMP Versions</p> <p>Arista switches support the following SNMP versions:</p> <ul style="list-style-type: none"> • SNMPv1: The Simple Network Management Protocol, defined in RFC 1157. Security is based on community strings. • SNMPv2c: Community-string based Administrative Framework for SNMPv2, defined in RFC 1901, RFC 1905, and RFC 1906. SNMPv2c uses the community-based security model of SNMPv1. • SNMPv3: Version 3 is an interoperable standards-based protocol defined in RFCs 2273 to 2275. SNMPv3 provides secure access to devices by authenticating and encrypting packets. <p>The security features provided in SNMPv3 are as follows:</p> <ul style="list-style-type: none"> — Message integrity: Ensures packets are not tampered with in transit. — Authentication: Determines the message is received from a valid source. — Encryption: Scrambling packet contents to prevent an unauthorized source from learning it. <p>Both SNMPv1 and SNMPv2c use a community-based form of security. The community of managers able to access the agent MIB is controlled by a password.</p> <p>SNMPv2c support includes a bulk retrieval mechanism and more detailed error message reporting. The bulk retrieval mechanism supports the retrieval of tables and large quantities of information, minimizing the number of round-trips required. SNMPv2c error handling includes expanded error codes that distinguish different kinds of error conditions; these conditions are reported through a single error code in SNMPv1. SNMPv2c error return codes report error type.</p> <p>SNMPv3 is a security model which defines an authentication strategy that is configured for a user and the group in which the user resides. A security level is the permitted level of security within the model. A combination of a security model and a security level determines the security mechanism employed to handle an SNMP packet.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 349.</p>
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>SNMPv3 uses contexts to distinguish between these multiple instances. An SNMP context is a collection of management information that you can access through the SNMP agent. A device can support multiple contexts for different logical network entities. An SNMP context allows the SNMP manager to access one of the multiple instances of a MIB module supported on the device for the different logical network entities.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 11-3.</p>	<p>An SNMP context is a collection of management information items accessible by an SNMP entity. Each item of may exist in multiple contexts. Each SNMP entity can access multiple contexts. A context is identified by the EngineID of the hosting device and a context name.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 1994.</p>
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 2 <code>vlan vlan</code></p> <p>Example:</p> <pre>switch(config)# vlan 901 switch(config-vlan)#</pre> <p>Enters VLAN configuration mode for the VLAN specified.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 16-18.</p>	<p>Example</p> <ul style="list-style-type: none"> • This command creates VLAN 49 and enters VLAN configuration mode for the new VLAN: <pre>switch(config)#vlan 49 switch(config-vlan-49)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 803.</p>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>To permit the discovery of non-Cisco devices, the switch also supports the <i>Link Layer Discovery Protocol (LLDP)</i>, a vendor-neutral device discovery protocol that is defined in the IEEE 802.1ab standard. LLDP allows network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer, which allows two systems running different network layer protocols to learn about each other.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-2.</p>	<p>Link Layer Discovery Protocol (LLDP) allows Ethernet network devices to advertise details about themselves, such as device configuration, capabilities and identification, to directly connected devices on the network that are also using LLDP.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 572.</p>
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Guidelines and Limitations</p> <p>LLDP has the following configuration guidelines and limitations:</p> <ul style="list-style-type: none"> • LLDP must be enabled on the device before you can enable or disable it on any interfaces. • LLDP is supported only on physical interfaces. • LLDP can discover up to one device per port. • LLDP can discover Linux servers, provided they are not using a converged network adapter (CNA). LLDP cannot discover other types of servers. • DCBXP incompatibility messages might appear when you change the network QoS policy, if a physical loopback connection is in the device. The incompatibility exists for only a short time and then clears. • DCBXP is not supported for the Cisco Nexus 2000 Series Fabric Extender. • Beginning with Cisco NX-OS Release 5.2, LLDP is supported for the Cisco Nexus 2000 Series Fabric Extender. LLDP packets can now be sent and received through the Fabric Extender ports for neighbor discovery. <ul style="list-style-type: none"> – All LLDP configuration on Fabric Extender ports occurs on the supervisor. LLDP configuration and show commands are not visible on the Fabric Extender console. – LLDP is not supported for a Fabric Extender-virtual port channel (vPC) connection. <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-2.</p>	<p>12.2.4 Guidelines and Limitations</p> <p>LLDP has the following configuration guidelines and limitations:</p> <ul style="list-style-type: none"> • LLDP must be enabled on the device before you can enable or disable it on any interface. • LLDP is supported only on physical interfaces. • LLDP can discover up to one device per port. <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 576.</p>

Copyright Registration Information	Cisco	Arista															
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Enabling or Disabling LLDP on an Interface</p> <p>After you globally enable LLDP, it is enabled on all supported interfaces by default. However, you can enable or disable LLDP on individual interfaces or selectively configure an interface to only send or only receive LLDP packets.</p> <p>Note If the interface is configured as a tunnel port, LLDP is disabled automatically.</p> <p>BEFORE YOU BEGIN</p> <p>Make sure that you are in the correct VDC. To switch VDCs, use the <code>switchto vdc</code> command.</p> <p>Make sure that you have globally enabled LLDP on the device.</p> <p>SUMMARY STEPS</p> <ol style="list-style-type: none"> 1. <code>conf t</code> 2. <code>interface ethernet slot/port</code> 3. <code>[no] lldp transmit</code> 4. <code>[no] lldp receive</code> 5. (Optional) <code>show lldp interface ethernet slot/port</code> 6. (Optional) copy running-config startup-config <p>DETAILED STEPS</p> <table border="1"> <thead> <tr> <th>Step</th><th>Command</th><th>Purpose</th></tr> </thead> <tbody> <tr> <td>Step 1</td><td><code>conf t</code> Example: <code>switch# conf t</code> Enter configuration commands, one per line, and with Ctrl/Z. <code>switch(config)#</code></td><td>Enters global configuration mode.</td></tr> <tr> <td>Step 2</td><td><code>interface ethernet slot/port</code> Example: <code>switch(config)# interface ethernet 7/1</code> <code>switch(config-if)#</code></td><td>Specifies the interface on which you are enabling LLDP and enters the interface configuration mode.</td></tr> <tr> <td>Step 3</td><td><code>[no] lldp transmit</code> Example: <code>switch(config-if)# lldp transmit</code></td><td>Enables or disables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</td></tr> <tr> <td>Step 4</td><td><code>[no] lldp receive</code> Example: <code>switch(config-if)# lldp receive</code></td><td>Enables or disables the reception of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-6.</p>	Step	Command	Purpose	Step 1	<code>conf t</code> Example: <code>switch# conf t</code> Enter configuration commands, one per line, and with Ctrl/Z. <code>switch(config)#</code>	Enters global configuration mode.	Step 2	<code>interface ethernet slot/port</code> Example: <code>switch(config)# interface ethernet 7/1</code> <code>switch(config-if)#</code>	Specifies the interface on which you are enabling LLDP and enters the interface configuration mode.	Step 3	<code>[no] lldp transmit</code> Example: <code>switch(config-if)# lldp transmit</code>	Enables or disables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.	Step 4	<code>[no] lldp receive</code> Example: <code>switch(config-if)# lldp receive</code>	Enables or disables the reception of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.	<p>12.3.2 Enabling LLDP on an Interface</p> <p>After you globally enable LLDP, it is enabled on all supported interfaces by default. However, by using the <code>lldp transmit</code> and <code>lldp receive</code> commands, you can enable or disable LLDP on individual interfaces or selectively configure an interface to only send or only receive LLDP packets.</p> <p>Examples</p> <ul style="list-style-type: none"> These commands enable Ethernet port 3/1 to transmit LLDP packets. <pre>switch(config)# interface ethernet 3/1 switch(config-if-Et3/1)# lldp transmit switch(config-if-Et3/1)#</pre> These commands enable Ethernet port 3/1 to receive LLDP packets. <pre>switch(config)# interface ethernet 3/1 switch(config-if-Et3/1)# lldp receive switch(config-if-Et3/1)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 577.</p>
Step	Command	Purpose															
Step 1	<code>conf t</code> Example: <code>switch# conf t</code> Enter configuration commands, one per line, and with Ctrl/Z. <code>switch(config)#</code>	Enters global configuration mode.															
Step 2	<code>interface ethernet slot/port</code> Example: <code>switch(config)# interface ethernet 7/1</code> <code>switch(config-if)#</code>	Specifies the interface on which you are enabling LLDP and enters the interface configuration mode.															
Step 3	<code>[no] lldp transmit</code> Example: <code>switch(config-if)# lldp transmit</code>	Enables or disables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.															
Step 4	<code>[no] lldp receive</code> Example: <code>switch(config-if)# lldp receive</code>	Enables or disables the reception of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.															

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 3 <code>[no] lldp transmit</code></p> <p>Example: <code>switch(config-if)# lldp transmit</code></p> <p>Enables or disables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-6.</p>	<p>lldp transmit</p> <p>The lldp transmit command enables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</p> <p>Platform all Command Mode Interface-Ethernet configuration Interface-Management configuration</p> <p>Command Syntax</p> <p><code>lldp transmit</code> <code>no lldp transmit</code> <code>default lldp transmit</code></p> <p>Examples</p> <ul style="list-style-type: none"> These commands enable the transmission of LLDP packets on a specific interface. <pre>switch(config)#interface ethernet 4/1 switch(config-if-Et4/1)#lldp transmit switch(config-if-Et4/1)#</pre> <ul style="list-style-type: none"> These commands disable the transmission of LLDP packets on a specific interface. <pre>switch(config)#interface ethernet 4/1 switch(config-if-Et4/1)#no lldp transmit switch(config-if-Et4/1)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 593.</p>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 4 <code>[no] lldp receive</code></p> <p>Example: <code>switch(config-if)# lldp receive</code></p> <p>Enables or disables the reception of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-6.</p>	<p>lldp receive</p> <p>The <code>lldp receive</code> command enables the reception of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default. The <code>no</code> form of the command disables the reception of LLDP packets on an interface.</p> <p>Platform all Command Mode Interface-Ethernet configuration Interface-Management configuration</p> <p>Command Syntax</p> <p><code>lldp receive</code> <code>no lldp receive</code> <code>default lldp receive</code></p> <p>Examples</p> <ul style="list-style-type: none"> These commands enable the reception of LLDP packets on a specific interface. <pre>switch(config)#interface ethernet 4/1 switch(config-if-Et4/1)#lldp receive switch(config-if-Et4/1)#</pre> <ul style="list-style-type: none"> These commands disable LLDP the reception of LLDP packets on a specific interface. <pre>switch(config)#interface ethernet 4/1 switch(config-if-Et4/1)# no lldp receive switch(config-if-Et4/1)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 588.</p>
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Configuring Optional LLDP Parameters</p> <p>You can configure the frequency of LLDP updates, the amount of time for a receiving device to hold the information before discarding it, and the initialization delay time. You can also select the TLVs to include in LLDP packets.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-7.</p>	<p>12.3.3 Optional LLDP Parameters</p> <p>You can globally configure the frequency of LLDP updates, the amount of time for a receiving device to hold the information before discarding it, and the initialization delay time. You can also select the TLVs to include in LLDP packets.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 577.</p>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>Step 2 (no) <code>lldp holdtime</code> <i>seconds</i></p> <p>Example: <code>switch(config)# lldp holdtime 200</code></p> <p>(Optional) Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.</p> <p>The range is 10 to 255 seconds; the default is 120 seconds.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-8.</p>	<p>12.3.3.2 Setting the LLDP Hold Time</p> <p>The <code>lldp holdtime</code> command specifies the amount of time in seconds that a receiving device should hold the information sent by the device before discarding it.</p> <p>Examples</p> <ul style="list-style-type: none"> This command specifies that the receiving device should retain the information for 180 seconds before discarding it. <code>switch(config)# lldp holdtime 180</code> <code>switch(config)#</code> This command reverts the LLDP hold time and to the default value of 120 seconds. <code>switch(config)# no lldp holdtime 180</code> <code>switch(config)#</code> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 578.</p>
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<p>(no) <code>lldp reinit</code> <i>seconds</i></p> <p>Example: <code>switch(config)# lldp reinit 5</code></p> <p>(Optional) Specifies the delay time in seconds for LLDP to initialize on any interface.</p> <p>The range is 1 to 10 seconds; the default is 2 seconds.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-8.</p>	<p>lldp reinit</p> <p>The <code>lldp reinit</code> command specifies the delay time in seconds for LLDP to initialize on any interface.</p> <p>Platform all Command Mode Global Configuration</p> <p>Command Syntax</p> <p><code>lldp reinit delay</code> <code>no lldp reinit</code> <code>default lldp reinit</code></p> <p>Parameters</p> <ul style="list-style-type: none"> <i>delay</i> the amount of time the device should wait before re-initialization is attempted. Value ranges from 1 to 20 seconds; default value is 2 seconds. <p>Examples</p> <ul style="list-style-type: none"> This command specifies that the switch should wait 10 seconds before attempting to re-initialize. <code>switch(config)# lldp reinit 10</code> <code>switch(config)#</code> This command removes the re-initialize timer. <code>switch(config)# no lldp reinit 10</code> <code>switch(config)#</code> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 589.</p>

Copyright Registration Information	Cisco	Arista
<p>Cisco NX-OS 6.2</p> <p>Effective date of registration: 11/13/2014</p>	<div data-bbox="296 277 1146 505"> <p>Step 6 <code>[no] lldp tlv-select tlv</code></p> <p>Example: <code>switch(config)# lldp tlv-select system-name</code></p> <p>(Optional) Specifies the TLVs to send and receive in LLDP packets. The available TLVs are dcbxp, management-address, port-description, port-vlan, system-capabilities, system-description, and system-name. All available TLVs are enabled by default.</p> <p>Note For more information about using these TLVs, see the <i>Cisco Nexus 7000 Series NX-OS System Management Command Reference</i>.</p> </div> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 18-8.</p>	<div data-bbox="1167 277 2041 1295"> <h3>lldp tlv-select</h3> <p>The <code>lldp tlv-select</code> command allows the user to specify the TLVs to send and receive in LLDP packets. The available TLVs are management-address, port-description, port-vlan, system-capabilities, system-description, and system-name.</p> <p>Platform all Command Mode Global Configuration</p> <p>Command Syntax</p> <pre>lldp tlv-select TLV_NAME no lldp tlv-select TLV_NAME default lldp tlv-select TLV_NAME</pre> <p>Parameters</p> <ul style="list-style-type: none"> TLV_NAME the TLV specifies the information to be sent or received in the LLDP packet: Options include: <ul style="list-style-type: none"> <code>link-aggregation</code> specifies the link aggregation TLV. <code>management-address</code> specifies the management address TLV. <code>max-frame-size</code> specifies the Frame size TLV. <code>port-description</code> specifies the port description TLV. <code>port-vlan</code> specifies the port VLAN ID TLV. <code>system-capabilities</code> specifies the system capabilities TLV. <code>system-description</code> specifies the system description TLV. <code>system-name</code> specifies the system name TLV. <p>Example</p> <ul style="list-style-type: none"> This command enables the system description TLV: <pre>switch(config)# lldp tlv-select system-description switch(config)#</pre> This command disables the system description TLV: <pre>switch(config)# no lldp tlv-select system-description switch(config)#</pre> This command enables the max-frame-size TLV: <pre>switch(config)# lldp tlv-select max-frame-size switch(config)#</pre> This command disables the max-frame-size TLV: <pre>switch(config)# no lldp tlv-select max-frame-size switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 592.</p> </div>

Copyright Registration Information	Cisco		Arista
Cisco NX-OS 6.2 Effective date of registration: 11/13/2014	<div>show lldp traffic</div> <div></div>	<div>Displays the LLDP counters, including the number of LLDP packets sent and received by the device, the number of discarded packets, and the number of unrecognized TLVs.</div> <div></div>	<div>12.3.5.4 Viewing LLDP Traffic</div> <div>The show lldp traffic command displays the LLDP counters, including the number of packets sent and received, and the number of packets discarded by the switch.</div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (October 2, 2014), at 581.</div>